

EVA BASE ASSEMBLY

Great conversations start here.™

PARTS LIST

- (1) Spider
- (1) Column
- (1) Base
- (2) Bolts
- (2) Flat Washers
- (2) Lock Washers
- (3) Glides



TOOL LIST

- Adjustable Wrench / 3/4" Socket Wrench



ALIGN THE SPIDER WITH THE NOTCH ON THE TOP OF THE COLUMN



USING THE TWO FLAT WASHERS AND A BOLT ATTACH THE SPIDER TO THE COLUMN



FIRMLY TIGHTEN SPIDER TO THE COLUMN USING WRENCH.



ONCE FIRMLY TOGETHER TURN THE SPIDER AND COLUMN UPSIDE DOWN.

EVA BASE ASSEMBLY

Great conversations start here.™



IF NOT ALREADY ATTACHED, SCREW THE GLIDES INTO BOTTOM OF THE BASE.



CENTER THE BASE ONTO THE BOTTOM OF THE COLUMN USING THE TWO NUB HOLES AS A GUIDE.



USING THE TWO LOCK WASHERS AND BOLT ATTACH THE BASE TO THE COLUMN



FIRMLY TIGHTEN WITH WRENCH UNTIL SECURE.



FINISHED BASE